# How to use the **Energy Saver Pulse** (ESP) Instructions do not apply to "Blue" ESP control pad

#### FOR NORMAL DAILY OPERATION

- 1 After switching the towel warmer on at the mains switch, it will (after a short delay) start in ECOSAVE mode to provide the full electricity benefits of ESP power savings.
- 2 From now on, after using your towel, all you need to do is touch the ESP pad to activate a full power ECOBOOST cycle.\*

- 3 Your towel warmer will reset itself to ECOSAVE mode at the end of the 4 hour ECOBOOST cycle.
- 4 Therefore the next time you use your towel, simply repeat step 2 for another **ECOBOOST** cycle.

### **ECOSAVE**

POWER ON

Switch Towel Warmer on at mains. Device is in power saving mode.

LED shows 50/50 heartbeat-style on/off flash.







### **ECOBOOST**

Device will quickly warm to full power.

After 4 hours the device will automatically reset to **ECOSAVE** mode.

LED blinks once per second.

#### FOR CONTINUOUS OR FULL POWER OPERATION

1 To change from ECOSAVE to CONTINUOUS FULL POWER all the time, press hold the ESP touch pad. (Important: Press hold your finger on the ESP touch pad until the indicator light stops flickering.) When in CONTINUOUS FULL POWER mode you can return the towel warmer to ECOSAVE by a press hold of the ESP touch pad.

### **ECOSAVE**



Switch Towel Warmer on at mains. Device is in power saving mode.

LED shows 50/50 heartbeat-style on/off flash.







# CONTINUOUS FULL POWER

Device is always at full power.

During Press Hold, LED flashes vigorously until new mode is achieved.

Then LED is on continuously.

**PRESS HOLD:** Gently rest your finger on the ESP pad until the flickering of the light stops.

Warning! DO NOT drape towels over the ESP control pad. Note: During electrical work the unit must be turned off at its supply switch or at mains. The trademarks Energy Saver Pulse and Heirloom ESP are the property of Heirloom International Limited.

**Congratulations** on purchasing your new Heirloom Towel Warmer. We are sure you will enjoy the luxury of having snuggly warm towels.

**Designed for continuous use,** this towel warmer is **a heating appliance** and should be treated as such. It is not intended for use by young children or infirm persons without supervision.

A towel warmer is designed to warm and assist the drying of towels and will normally operate at a temperature that is too hot for the warmer to be grasped for an extended time.

The heat of this unit will fluctuate according to the room temperature and may increase if overloaded with towels.

**Care and Cleaning:** Clean regularly with a damp cloth and gentle cleaning agent. Do not use harsh or ammoniated cleaners.

For over 25 years, Heirloom have been Australasian leaders in the design and production of towel warmers. We are respected for reliable, safe and proven element technology.

# Heirloom offers peace of mind with:



All Heirloom towel warmers have an IP45 rating, allowing for safe installation, especially in bathrooms Zone 1, the area next to baths and showers.



Heirloom ESP™ controller is supported by a 2 year warranty.

Store this leaflet in a safe place for future use.

For further information call our customer helpline New Zealand **0800 434 756** Australia **07 3271 1944** or visit **www.heirloom.co.nz** 





